Infrared APC Laser Module APCD-780-06-XX-A/B

6-2D-LM78-004 Rev.00

Φ6.5mm Plastic 780nm Laser Module

Power set by user

Features

- APC (auto power control) IC inside 1.
- High quality PC lens 2.
- 3. Low current consumption of the APC circuit
- 4. Superior laser beam profile




Absolute maximum ratings

Item	Symbol	Rating	Unit
Power supply voltage	V _{cc}	3.3	V
Laser Module optical output power	Po	<3	mW
Operation temperature	T _{opr}	0~40	°C
Storage temperature	T _{stg}	0~60	°C

Electrical and optical characteristics (T_c=25 °C)

ltem	Symbol	Min.	Тур.	Max	Unit	Condition	
Wavelength	λ	-	785	-	nm	P₀= 3mW	
Operation current	l _{op}	-	-	35	mA	P _o = 3mW V _{cc} =3V	
Operation voltage	V _{op}	2.5	-	3.3	Volt		
Laser Beam spot size at 10m	<20mm						
Divergence angle	2 mrad						
Mean time to failure (MTTF) 25°C	>10000 hrs						

Outline dimensions (Units: mm)



Laser Safety Precautions

- 1. Do not look into the laser beam directly by eyes. The laser beam may cause severe damage to human eyes.
- 2. Optical Lens is made of plastic or glass. Do not contaminate lens by soiling, oil or chemical...


Page 1/2



6-2D-LM78-004 Rev.00

APCD-780-06-XX-A/B

PIN Assignment:




 Pin 1:
 Vcc

 Pin 2:
 GND

 Pin 3:
 PD

A type : Heat sink stand (-)



B type :Heat sink stand (+)

PD本≠

3 R×13 Vcc

≉¢LD


APC

L C×1

Laser power Adjustment Procedure

- 1. Connect 1 uF capacitor (Cx1) between Pin1 and Pin2.
- Connect 20~50K ohm variable resistor (Rx1) between Pin2 and Pin3.
- 3. Set Vcc to the designed value.
- 4. Adjust Rx1 to obtain the desired output power.
- 5. Laser Safety Precautions
 - (1) Do not increase Vcc value when the laser module is working near the maximum power . That is to protect laser from overdriving condition and make sure power is under 3 mW.
 - (2) Do not operate the device above the maximum rating condition, even momentarily. It may cause unexpected permanent damage to the device.

Laser power stability



Page 2/2

